



PERGOLUX

SCREEN S2 3m and 4m Skydance

Use this instructions if you have a:

PERGOLUX Skydance S2 3m/4m



PERGOLUX

Congratulations and thank you for choosing a PERGOLUX Product!

To enjoy this product for a long time as well as for your own and others' safety, please follow the installation instructions. Before you start assembling and using the pergola, ensure that all the parts listed in the manual are delivered and intact. If you need help with the installation, you can contact us by chat, phone, e-mail or at our website.

We wish you good luck with the assembling process!

Contact:



Germany



United Kingdom



United States



Denmark



Sweden



Norway



Australia



France



Switzerland



Italy



Netherlands



Austria



Chile
contacto@pergolux.cl



Brazil
contato@pergolux.com.br

PERGOLUX

Having some issues or submit a claim?

If you are faced to an issue with your PERGOLUX products and needs to submit a claim please read this article:



[Complaints and Technical Issues](#)



[Reklamation einreichen. Schritt für Schritt Anleitung](#)

Submit the claim here:



[Submit a request](#)



[Anfrage einreichen](#)



[Een aanvraag indienen](#)



[Enviar una solicitud](#)



[Envoyer une demande](#)



[Send oss en henvendelse](#)





[Skicka oss en förfrågan](#)





[Send os en forespørgsel](#)

PERGOLUX


SCREEN S2



T20 safety torx bit




Ø 2mm





PERGOLUX

SCREEN S2 4m PN-200001734




PERGOLUX


SCREEN S2 4m PN-200001734



DETAIL A




SECTION B-B



SECTION E-E



PERGOLUX

SCREEN S2 3m PN-200001700




PERGOLUX


SCREEN S2 3m PN-200001700



DETAIL A



SECTION B-B



SECTION C-C

PERGOLUX

SCREEN S2 3m and 4m



①

1x



⑨

2x



②

2x



⑩

12x



③

2x



PN-200001695

2x Pre-assembled part



8x20

⑥

4x




⑦

8x




⑧

2x





2x






6x

These screws are in the package but should not be used, they are not needed on this model







1





2








3




4




5




6





7




x2



8





9







x8

10






x8




11




12






13



14



15



PERGOLUX

SCREEN S2

